

Ref. No.	Part No.	Part Name & Description	Remarks
C129	ECUV1C104ZEV	0.1	
C130	ECEA1AKA101	100	
C131	ECUV1C104KBV	0.1	
C132	ECUV1C104KBV	0.1	
C133	ECUV1H390JCV	39p	

24.2. Handset

24.2.1. CABINET AND ELECTRICAL PARTS

Ref. No.	Part No.	Part Name & Description	Remarks
101	PQJT10182Z	CHARGE TERMINAL	
102	PQGT15033Z	NAME LABEL (for KX-TC1205RUB)	
102	PQGT14903Z	NAME LABEL (for KX-TC1205RUW)	
102	PQGT14904Z	NAME LABEL (for KX-TC1205RUS)	
102	PQGT14905Z	NAME LABEL (for KX-TC1205RUF)	
103	PQKF10535Y1	REAR CABINET (for KX-TC1205RUB)	S
103	PQKF10535Y5	REAR CABINET (for KX-TC1205RUW)	S
103	PQKF10535Y4	REAR CABINET (for KX-TC1205RUS)	S
103	PQKF10535Y2	REAR CABINET (for KX-TC1205RUF)	S
104	PQKK10124Z1	BATTERY COVER (for KX-TC1205RUB)	S
104	PQKK10124Z5	BATTERY COVER (for KX-TC1205RUW)	S
104	PQKK10124Z4	BATTERY COVER (for KX-TC1205RUS)	S
104	PQKK10124Z2	BATTERY COVER (for KX-TC1205RUF)	S
105	PQKM10510W1	FRONT CABINET (for KX-TC1205RUB)	S
105	PQKM10510W5	FRONT CABINET (for KX-TC1205RUW)	S
105	PQKM10510W4	FRONT CABINET (for KX-TC1205RUS)	S
105	PQKM10510W2	FRONT CABINET (for KX-TC1205RUF)	S
106	PQSA10084U	ANTENNA (for KX-TC1205RUB/KX-TC1205RUF)	
106	PQSA10084V	ANTENNA (for KX-TC1205RUW/KX-TC1205RUS)	
107	PQSX10191Z	KEYBOARD SWITCH (for KX-TC1205RUB/KX-TC1205RUF)	
107	PQSX10191V	KEYBOARD SWITCH (for KX-TC1205RUW)	
107	PQSX10191W	KEYBOARD SWITCH (for KX-TC1205RUS)	
108	PQXA36ASVC	BATTERY	
109	FH1T1200011	CUSHION, URETHANE FORM	
110	CG2P1200012	SPEAKER	
111	FE4T1200019	SP NET	
112	FH2T1200012	BUZZER SHEET	
113	PQHR10896Z	LIGHT PIPE	
114	FE4T1200027	MIC NET	

24.2.2. MAIN P.C.BOARD PARTS

Ref. No.	Part No.	Part Name & Description	Remarks
PCB100	PQWPC1205RUR	MAIN P.C.BOARD ASS'Y (RTL)	
		(ICS)	
IC1	SA133122409	IC	
IC2	SA138780731	IC	
		(TRANSISTORS)	
Q1	SB110390405	TRANSISTOR(SI)	
Q2	SB110390405	TRANSISTOR(SI)	
Q3	SB110390405	TRANSISTOR(SI)	
Q4	SB010390608	TRANSISTOR(SI)	
Q5	SB110390405	TRANSISTOR(SI)	
Q6	SB110390405	TRANSISTOR(SI)	

Ref. No.	Part No.	Part Name & Description	Remarks
Q7	SB010390608	TRANSISTOR(SI)	
Q8	SB110390405	TRANSISTOR(SI)	
Q9	SB110390405	TRANSISTOR(SI)	
Q11	SB110390405	TRANSISTOR(SI)	
		(DIODES)	
D1	SC15L414808	DIODE(SI)	
D2	SC15L414808	DIODE(SI)	
D3	SC15L414808	DIODE(SI)	
DV1	BC6K0025101	DIODE(SI)	
ZD1	BC4579C1005	DIODE(SI)	
ZD3	SC455C5V601	DIODE(SI)	
		(LEDS)	
LED1	SC5E0192115	LED	
LED2	SC5E0192115	LED	
LED3	SC5E0192115	LED	
LED4	SC5E0192115	LED	
LED5	SC5E0192115	LED	
LED6	SC5E0192123	LED	
		(COILS)	
L1	PQLQZKR68J	COIL	
L2	PQLQZM120K	COIL	
L3	PQLQZM120K	COIL	
L4	PQLQZK120J	COIL	
L5	PQLQZK120J	COIL	
L6	PQLQZK1R8J	COIL	
L7	SH590121N75	COIL	
		(CERAMIC FILTERS)	
CF1	BDFL107MA53	CERAMIC FILTER	
CF2	BDFL0455E02	CERAMIC FILTER	
DPX1	BDFL0083012	CERAMIC FILTER	
		(CRYSTAL OSCILLATORS)	
X1	BD5R1024501	CRYSTAL OSCILLATOR	
X2	BD8R3276805	CRYSTAL OSCILLATOR	
X3	BD1R0399202	CRYSTAL OSCILLATOR	
		(TRANSFORMERS)	
T1	CLIP1200053	TRANSFORMER	
T3	CLIP1200070	TRANSFORMER	
T5	CLIP1200061	TRANSFORMER	
T6	CLIP1200088	TRANSFORMER	
		(OTHERS)	
E101	CK15HC12G10	RINGER	
E102	CGAP1200019	MICROPHONE	
E103	PQJT10183Z	CHARGE CONTACT	
BATT1	PQJP2D13Z	CONNECTOR	
VC1	CR00020RRT5	TRIMMER CAPACITOR	
		(RESISTORS)	
R1	ERJ3GEYJ331	330	
R2	ERJ3GEYJ153	15k	
R3	ERJ3GEYJ682	6.8k	
R5	ERJ3GEYJ103	10k	
R6	ERJ3GEYJ103	10k	
R8	ERJ3GEYJ224	220k	
R9	ERJ3GEYJ823	82k	
R10	ERJ3GEYJ823	82k	
R11	ERJ3GEYJ562	5.6k	
R12	ERJ3GEYJ224	220k	
R13	ERJ3GEYJ123	12k	
R14	ERJ3GEYJ153	15k	
R15	ERJ3GEY0R00	0	
R16	ERJ3GEYJ103	10k	
R17	ERJ3GEYJ512	5.1k	
R18	ERJ3GEYJ103	10k	
R19	ERJ3GEYJ472	4.7k	
R20	ERJ3GEYJ182	1.8k	
R21	ERJ3GEYJ823	82k	
R22	ERJ3GEYJ472	4.7k	
R23	ERJ3GEYJ473	47k	
R24	ERJ3GEYJ472	4.7k	
R25	ERJ3GEYJ563	56k	
R26	ERJ3GEYJ103	10k	
R28	ERJ3GEYJ124	120k	
R29	ERJ3GEYJ682	6.8k	
R30	ERJ3GEY0R00	0	